



Camping-WiFi.eu

WIFI ON THE CAMPING

Usrguide HOLIDAYSIM-only

APN: 3internet

No username - No password - No authorisation code

Switch OFF roaming on your devices if you use a WiFi-Hotspot. Switch ON roaming on your devices if you do not use a hotspot. The sim will connect to a local network.

In case of slow internet or no internet, connect manually to our roaming partner. (In the Camping-wifi.eu-dongle go to 192.168.8.1 login with admin/admin > Home>disconnect>network select >manual>apply and select a partner-network>apply. In the ZTE-MiFi go to 192.168.0.1 log in with pw: admin>Settings>Network Settings>Network Selection>Manual)

ROAMING PARTNERS

UK: 3. Ireland: 3 en O2. Italy: 3 and WIND. Spain: Orange, Movistar, Yoigo. France: Orange, FreeMobile, Bouygues. Austria: Hutchison Drei. Switzerland: Sunrise. Norway: Telenor. Sweden: 3. Finland: Elisa, Alands. Denmark: 3. USA: AT&T. Australia: Telstra, Vodafone Hutchison, yes Optus. Indonesia: Hutchison 3. Hong Kong: 3. Israel: Orange, Pelephone. New Zealand: Two Degrees. Macau: 3. Sri Lanka: Hutchison, Mobitel

Recharge: www.kampeerwifi.nl

TIPS: Switch OFF automatic updates in your appstore and on your devices. Please be advised that streaming (audio&video) uses large amounts of data (250MB/hr) . Streaming is best done in WiFi Zones.

Read your newspaper on the mobile site of your newspaper which starts with m.

1GB = 10.000 text e-mails or 60 hours browsing or 3000 photos or 100 hours GPS navigation or 4 hours Skyping

Contact: info@myprivatehotspot.com SMS: +31612885413 Tel: +31355384050 (mention CODE)